


Installation Manual

MITSUBISHI LANCER 4DR
MIT-LANG-4-A



COMPONENTS INCLUDED



x 2



x 2



CL-M01 x 8



CL-P03 x 4



CL-W01 x 1





CL-A01 x 1



Installation

MITSUBISHI LANCER 4DR




MIT-LANC-4-A



Installation

MITSUBISHI LANCER 4DR

MIT-LANG-4-A



Installation

MITSUBISHI LANCER 4DR

MIT-LANC-4-A

